BioStar Lite

User Manual

Version V1.0

www. supremainc.com

Quality Assurance

Warranty

Suprema warrants the performance of the product specified in the specifications within the limitations set forth for a warranty period of one year from the date of delivery to the purchaser. If the purchaser claims any defects covered in this warranty in writing within the warranty period, then Suprema will repair or replace and deliver the defective product that is returned within the warranty period; provided that the purchaser shall be responsible for any transportation cost (including insurance for overseas shipping). This warranty does not apply to: (1) damage caused by strong external physical impact, overcurrent, misuse, abuse, or negligence; (2) damage to the product that has been improperly repaired, remodeled, or modified without the written permission of the provider; or (3) damage to the product that has been installed or used contrary to the manual provided by Suprema. Claims for any defects must be submitted to Suprema in writing by using the Return Material Authorization Report provided by Suprema within 30 days of the finding of the defect or within 1 year from the date of delivery. The Return Material Authorization Report must include the detailed information, model number, invoice number, and serial number of the defective product. A product without the return authorization number issued by Suprema is not considered to be eligible for the warranty. All defects must be reproducible. Excluding the above-mentioned warranties and remedies, this product is provided as-is without any expressed or implied warranties regarding product warranty, commercial viability, or availability for a particular purpose.

Disclaimer

The information in this document is provided in connection with Suprema products. No license, expressed or implied, by estoppels or otherwise, to any intellectual property rights is granted by this document, except as provided in Suprema's Terms and Conditions of Sale for such products. Suprema assumes no liability whatso ever and Suprema disclaims any expressed or implied warranty, relating to sale and/or use of Suprema products, including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright, or other intellectual property right. Suprema products are not intended for use in medical, life saving, or life sustaining applications or other applications in which the failure of the Suprema product could create a situation where personal injury or death may occur. Should Buyer use Suprema products for any such unintended or unauthorized applications, Buyer shall indemnify and hold Suprema and its employees, head quarters, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Suprema was negligent regarding the design or manufacture of the part. Suprema reserves the right to make changes to specifications and product descriptions at any time without notice to improve reliability, function, or design. Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Suprema reserves these for future definitions and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

Contents

Quality Assurance 2

Chapter 1

Getting Started 8

Features 8

Key Features 9

Connecting and Executing 10

Chapter 2

Using Basic Menus 12

Screen View 12

Device Management 14

Adding Devices 14

Viewing the Device Information 15

Door Management 17

Adding Doors 17

Modifying Door Information 19

Closing Doors 20

Opening Doors 20

Setting a Language 21

Viewing the Help Manual 21

Checking the BioStar Lite Firmware Version 21

Administrator Account Management 22

Adding or Modifying an Administrator Account 22

Deleting an Administrator Account 23

Logout 23

Chapter 3

Using the Home Menu 25

Screen View 25

Using Quick Menus 26

Chapter 4

Using the User Menu 28

Screen View 28

Searching Users 29

New User Registration 30

Entering General Information 31

Registering a Card 32

Scanning a Fingerprint 32

User Information Modification 33

Updating General Information 34

Modifying Card Information 34

Modifying Fingerprint 34

Chapter 5

Using the Log Menu..... 36

Monitoring Event Logs 36

Search Logs..... 37

Screen View 37

Search Logs 38

Chapter 6

Using the Device Menu 42

Authentication Mode Configuration..... 42

Setting Fingerprint Authentication..... 43

Setting Card Authentication 43

Setting ID Authentication 43

Setting Other Options..... 43

Setting Network 44

Setting IP Address..... 45

Setting WLAN 45

Setting Serial..... 46

Setting Display and Sound Options..... 47

Setting Time..... 48

Setting Language..... 48

Setting Background 48

Setting Theme..... 48

Setting Menu Timeout 49

Setting Popup Timeout..... 49

Setting Backlight Timeout 49

Setting Show Central Clock Display..... 49

Setting Data Format..... 49

Setting Volume..... 49

Setting Card or Fingerprint Options..... 50

Setting a Card Option..... 51

Setting a Fingerprint Option..... 51

Chapter 7

Using the Access Control Menu .. 54

Screen View 54

Holiday Group Managment..... 55

Adding a Holiday..... 55

Modifying a Holiday..... 56

Delete a Holiday 56

Timezone Management..... 57

Adding a Time Zone..... 57

Modifying a Time Zone 58

Deleting a Time Zone..... 59

Access Group Management..... 60

Adding an Access Group 60

Modifying an Access Group..... 61

Deleting an Access Group..... 61

Chapter 8

Using the System Profile Menu... 63

Screen View 63

System Configuration Management..... 64

Backup System Configuration .. 64

Restore System Configuration... 64

User Information Management..... 65

Backup User Information..... 65

Restore User Information 65

Language Resource Management .. 66

Download Language Resource. 66

Upload Language Resource..... 66

Appendix..... 68

Understanding the Product Details 68

Introducing Devices Supporting BioStar Lite..... 68

Notes for Authenticating Fingerprints on the Device 69

Authentication Mode Supported by Devices..... 70

Detailed Diagram 71

Device Connections 71

Door Connections..... 72

Troubleshooting 73

Glossary..... 74

Index..... 76

Chapter 1

Getting Started

Features

Key Features

Connecting and Executing

Getting Started

Features

- **Distributed Intelligence Access Control System**
  Suprema's distributed intelligence approach requires less hardware and less wiring than the conventional, centralized access control systems. User information, access rules, and other data can be distributed to each device to speed up authorization time and provide continual operation even when the network connection is cut off.

- **Combination of Conventional Access Control and Biometrics**
  Compared to conventional access control systems, this product was further developed to support biometric identification and access card configuration features.

- **Convenient Network Connection that Supports Both TCP/IP and RS485**
  Devices can be either connected via Ethernet or wirelessly to a local area network or directly connected via serial connections (RS485).

- **High-level Access Security Controls**
  In order to provide access control with higher level security, Suprema's access control devices incorporate state-of-the-art fingerprint recognition algorithms that won two consecutive first-place awards in the fingerprint authentication contest (FVC2004 and FVC2006).

Key Features

BioStar Lite is a system suitable for a small-sized access control environment with less than 10 devices, which provides a convenient, easy access control management to the user via a simple and intuitive UI.

- **Managing Users**

  BioStar Lite provides features for searching, adding, deleting, and modifying users according to the user information registered on the devices with an operating web-server. Any changes from adding/modifying/deleting the user will be applied to all devices on the BioStar Lite system. Please refer to '**Using the User Menu'** for details regarding managing users.

- **Managing Event Logs**

  BioStar Lite supports real-time monitoring and searching for event logs. Log monitoring and search are available on all devices on the BioStar Lite system.

- **Managing Access Group**

  BioStar Lite supports 32 holiday schedules, 128 time frames, and 128 access groups. Each time frame can be set with 5 time periods for each day of the week or 5 time periods for 2 holiday schedules selected from 32 schedules.

  Each access group consists of a total of 32 'time frames per device.

  A user in a particular access group can be authenticated within the time frame registered on a device belonging to a corresponding access group.

  Any changes from adding, modifying, or deleting access control items will be applied to all devices on the BioStar Lite system. Please refer to '**Access Group Management**' for details regarding the access group.

- **Managing Doors**

  Up to 10 doors can be remotely controlled with BioStar Lite. 2 devices can be installed in a door, which can be remotelly opened or closed by the BioStar Lite. Please refer to '**Door Management**' for details regarding managing doors.

- **Managing Devices**

  The administrator can set the settings of up to 10 devices with BioStar Lite. Also, the administrator can adjust settings such as an authentication mode, communication settings, actions, screens, and sounds. All settings regarding the operating mode, display, volume, or fingerprint options modified on BioStar Lite will be applied to all devices on the BioStar Lite system. Please refer to **'Using the Device Menu'** for details regarding managing devices.

Connecting and Executing

Connection and execution are available on devices that have a BioStar Lite server.

1 Press **Menu** > **Network** > **TCP/IP** > **Use BioStar Lite**.

2 Press **Menu** > **Network** > **TCP/IP** and check IP address currently set in the device.

> **NOTE**
>
> • The default value is 127.0.0.1' If the IP address in the device is set as '127.0.0.1', ask network administrator for the IP setup.

3 Enter IP address to Web browser such as Internet Explorer or Chrome.

4 Check if BioLite Net is connected to the associated device correctly.

If at least one login user is registered, a login screen is displayed when accessing BioStar Lite. When logging in as a registered user, the Home screen is displayed.

> **NOTE**
>
> • Only one concurrent connection can be allowed for BioStar Lite.

Chapter 2

Using Basic Menus

Screen View

Device Management

Adding Devices

Viewing the Device Information

Door Management

Adding Doors

Modifying Door Information

Closing Doors

Opening Doors

Setting a Language

Viewing the Help Manual

Checking the BioStar Lite Firmware Version

Administrator Account Management

Adding or Modifying an Administrator Account

Deleting an Administrator Account

Logout

Using Basic Menus

Screen View



① **Menu Button**: Go to the relevant menu by clicking a menu button from different menus.

- **Home**: Go to the Home menu.
- **User**: Go to the User menu.
- **Log**: Go to the Log menu.
- **Device**: Go to the Device menu.
- **Access Control**: Go to the Access Control menu.
- **System Profile**: Go to the System Profile menu.

② **Language Button**: Set a language to be displayed on the screen.

③ **Help Button**: View Help for the relevant menu.

④ **Account Button**: View or modify an account to log in to BioStar Lite, or register a new account.

⑤ **Version Button**: Check the firmware version of the BioStar Lite.

⑥ **Logout Button**: Log out from the system if logged in with a registered account.

⑦ **Menu Activation Window**: A menu screen is displayed when each menu button is pressed.

⑧ **Door Management Window**

- **Close**: Remotely select and close a door.
- **Open**: Remotely select and open a door.
- **Setup**: Modify the information of the registered door.
- **Add**: Add doors to be controlled to the system.

⑨ **Device Management Window**

- **Info**: View the detailed information of a device.
- **Add**: Search and add a device connectable with BioStar Lite.

Device Management

From the device list, you can view devices that are connected to BioStar Lite.
Before adding devices, write down the location, ID, and IP address of each device so as to easily add devices. Static IP addresses are recommended for devices to be connected with BioStar Lite.

Adding Devices

1 Click **Add**. A pop-up window for searching devices is displayed.

2 Select a desired search method.



- **UDP Search**: Displays all devices available on the same network.
- **TCP Search**: Searches devices by entering the IP address and port.
- **RS485 Search**: Searches devices connected via RS485.

3 From the list of devices found, check the desired device(s).

4 Click **OK**. The selected device will be displayed on the list.

5 Click the red icon that appears beside the registered device(s) to synchronize the device.

NOTE

- In synchronizing the settings for the users, the connected devices and the access groups are synchronized. The settings for the users, connected devices, and access groups are synchronized.
- A maximum of 9 sub-devices can be registered into the BioStar Lite.

Viewing the Device Information

1 From the device list, select a desired device.
The selected device will be displayed in blue.

Refer to the **'Device Connections (Page 71)'** for details on connecting devices.

2 Click **Info** to view the detailed device information.

3 You can perform the **Factory Reset**, **Upgrade**, **Reboot**, **Remove**, or **Check Status**.



- **Factory Reset:** Initializes the device tio it's factory defaults (Does not affect log or user data).
- **Upgrade**: Upgrades the firmware.
  i. Click **Upgrade**.
  ii. Click **Browse** and select a path where the latest firmware is saved.
  iii. Click **Apply** to upgrade to the selected firmware.
  Click **Cancel** to cancel upgrade.
- **Reboot**: Reboots the device.
- **Remove:** Removes the selected device from the device list.
- **Check Status**: Tests the network connection to the device.

4 You can change the name of the device on the Device Detail screen.

5 Click **Apply** to save any changes.
Click **Cancel** to close the pop-up window.

NOTE

- Click [X] on the top right corner in order to close the pop-up window.

Door Management

The door list contains a list of all the registered doors with their respective devices. It will indicate teh status of a door if it was manually controlled.

Refer to the **'Door Connections (Page 72)'** for details regarding door information.



Adding Doors

1 Click **Add**. A pop-up window for adding doors is displayed.

2 Enter a desired door name.



3 Configure the door.

- **Entry**: Sets the device to control entry into the room/building.
- **Exit**: Selects a device control exit from a room/building.
- **Relay**: Sets a door relay.
- **Duration (sec)**: Sets a duration (sec) for the door to be held open. After the period, the relay will become deactivated.
- **RTE**: Sets an input trigger to open the door.
- **RTE Type**: Sets an input type to be used for the RTE (Request to Exit). (N/C: Normally Closed or N/O: Normally Open)
- **Door Sensor**: Sets a sensor input that detects the door status.
- **Door Sensor Type**: Sets an input type to be used for the door sensor. (N/C: Normally Closed or N/O: Normally Open)
- **Held Open Time (sec)**: Sets a duration (sec) a door must remain open for an alarm to trigger.
- **Unlock Time**: Sets a scheduled time when the door will remain unlocked.
- **Lock Time**: Sets the schedule when the door will remain locked.
- **Use Anti-passback**: Enables or disables the APB (anti-passback) feature.

4 Click **Add** to register the new door in the door list.
Click **Cancel** to close the window.

NOTE

- A red icon appears after a door is initially added. Click the red icon to synchronize the settings for the added device with the user's information.
- APB (anti-passback) is a feature to limit the access of users with no entrance or departure record. Therefore, this feature distinguishes 'IN Devices' and 'OUT Devices' and allows only users authenticated on the 'IN Device' to be authenticated on the 'OUT Device' and vice versa.
- The APB (anti-passback) feature can be set only if a device is installed on both the inside and outside of the door.

Modifying Door Information

1 From the Door List, select a desired door.
The selected door will be displayed in blue.



2 Click **Setup**. A window for changing the door will be displayed.



3 Update the desired field.

- Refer to the **'Adding Doors (Page 17)'** section.

4 You can change the door name on the Door Information screen.

5 Click **Apply** to update the door information.
Click **Remove** to remove the selected door from the door list.
Click **Cancel** to close the window.

Closing Doors

You can remotely close doors.

1 From the door list, select a desired door.

2 Click **Close** to close the selected door.

Opening Doors

You can remotely open doors.

1 From the door list, select a desired door.

2 Click **Open** to open the selected door.

NOTE

- The door relay which is remotely opened by the **Open** button on the BioStar Lite, will be held open unless it is closed by the **Close** button.

Setting a Language

You can set a language to be displayed on the BioStar Lite screen.

1 Click **Language**. A window for setting a language is displayed.

2 Select **English**, **Korean**, or **Custom**.



3 Click **Apply** to use the selected language on the displayed screen.
Click **Cancel** to cancel setting a language.

Viewing the Help Manual

You can view help manuals on the corresponding menu screen by clicking **Help**.



Checking the BioStar Lite Firmware Version

You can check the BioStar Lite Firmware version by clicking **Version** on the top right of the screen.

Administrator Account Management

You can view the registered login users by clicking **Account**.

Adding or Modifying an Administrator Account

1 Click **Account** on the top right of the screen. A window for adding an account is displayed.



2 Enter an administrator ID.

3 Enter the name of administrator.

4 Creat a password.

5 Re-enter the password to confirm.

6 Click **Add/Modify** to register or update an administrator account.

NOTE

- If you forget an account, you should reset the device that has a BioStar Lite server.
- When a BioStar Lite equipped device is reset, all of the door and device information are removed.

Deleting an Administrator Account

1 Click **Account** on the top right of the screen.

A window for changing an account is displayed.



2 Check the desired account(s).

3 Click **Delete** to delete the selected accounts.

NOTE

- If no administrator account registered on the list, the BioStar Lite will automatically enter into the Home menu.
- If at least one login user is registered, a login screen is displayed when you access BioStar Lite. You return to the Home screen after the registered user is logged in.



- A maximum of 5 BioStar Lite administrator accounts can be created. Then login ID can only include the numbers from 1 to 4294967295.

Logout

1 Click **Logout** on the top right of the screen.

NOTE

- In order to logout an BioStar Lite, administrator account must be created.

Chapter 3

Using the Home Menu

Screen View

Using Quick Menus

Using the Home Menu

Screen View

① **Home Menu Button**: Go to the Home menu by clicking this button from a different menu.

② **Quick Icon**: Click an icon to go to the relevant menu.

Using Quick Menus

Select a quick menu icon to go to the relevant menu.

- Add, delete, or modify a user.
- Search a user.

- View event logs of all devices in real-time.

- Search event logs by period, user, or device.

Chapter 4

Using the User Menu

Screen View

Searching Users

New User Registration

Entering General Information

Registering a Card

Scanning a Fingerprint

User Information Modification

Updating General Information

Modifying Card Information

Modifying Fingerprint

Using the User Menu

The user management submenu is used to add, modify, or delete users within the user database. Updates to the user database will be applied to all the devices registered into the BioStar Lite.

Screen View



① **User Menu Button**: Go to the User menu by clicking this button from a different menu.

② **Information Window**: View the total number of registered users and fingerprints.

③ **User List**: View a list of registered users on the system and their relevant information.

④ **Delete All Button**: Delete all registered users on the system.

⑤ **Delete Button**: Delete selected users from the user list.

⑥ **New User Registration Button**: Register a new user's information on the system.

⑦ **Search Button**: Search registered users on the system.

NOTE

- When you click ID or Name among item titles at the top of the user list, users are sorted by ID or name.
- You can view ID, name, card ID and more on the user list.
- You can view or modify the user's general information by clicking a user from the user list.
- You can delete the selected user by clicking **Delete**.
- You can delete all registered users by clicking **Delete All**.

Searching Users

1 Click **Search**. A window for searching for a user is displayed.

2 Select a name or ID from the user drop-down menu.



3 Enter a the respective name or ID.

4 Click **Search** to display the search results.
Click **Cancel** to close the window.

New User Registration



1 Click **New** to begin registration.

2 Enter general information.

3 Enter card information. (This step can be skipped.)

4 Scan a fingerprint. (This step can be skipped.)

5 Click **Add** to register the new user.
Click **Cancel** to cancel registration.

NOTE

- Refer to from page 31 to page 32 for details on entering general inforamtion and card information, and scanning fingerprints.

Entering General Information



1 Enter a numerical ID.

2 Click **Check ID** to check for ID availability.
If not, the pop-up message for checking ID is displayed.

3 Enter a name.

4 Enter a desired PIN number.

5 Re-enter the PIN number to confirm.

6 Set a desired user level to **Normal** or **Admin**.

7 Set a private authentication mode. This mode will be prioritized over the device's default settings. Refer to **'Authentication Mode Configuration (Page 42)'** for details.

8 Set an access group for the user.
Each user can be a part of 4 different access groups.

NOTE

- A user in a particular access group can be authenticated within the time frame set on a device belonging to a corresponding access group. Refer to **Chapter 7 'Using the Access Control Menu (Page 53)'** for details regarding the access group.

Registering a Card

1 Click **Read** to register a card.

2 Follow the instructions displayed on the linked device.
If the scan is successful, the card ID will be displayed on the BioStar Lite.

3 Click **Delete** to delete the entered card ID.

Scanning a Fingerprint



1 Click **Scan** to register a fingerprint.

2 Follow the instructions displayed on the linked device. This process is repeated twice.

3 To register an additional fingerprint, repeat steps 1 and 2.
Please refer to **'Notes for Authenticating Fingerprints on the Device (Page 69)'** for details regarding registering fingerprints.

4 Click **Add** to register the scanned fingerprint.
Click **Cancel** to cancel registering the scanned fingerprint.

NOTE

- Upon success, an image of the fingerprint will be displayed.
- Click **Delete** next to the scanned fingerprint to delete corresponding fingerprint.

User Information Modification



1 Click on a desired user from the user list.

2 Update general information.

3 Update card information.

4 Update a fingerprint information.

5 Click **Apply** to apply the change.
Click **Cancel** to cancel the change.

Updating General Information

Refer to the section on **'New User Registration'**.

> **NOTE**
>
> - When modifying the general information, you cannot modify the user ID.

Modifying Card Information

Refer to the section on **'New User Registration'**.

Modifying Fingerprint

Refer to the section on **'New User Registration'**.

Chapter 5

Using the Log Menu

Monitoring Event Logs

Search Logs

Screen View

Search Logs

Using the Log Menu

Monitoring Event Logs

The log monitoring feature provides a consolidated real-time event driven log of all the devices registered in the BioStar Lite. New entries are added to the bottom of the list. The consolidated log will display a complete list of events even from devices that do not have a BioStar Lite server.



Time	Device ID	Device Name	User ID	Image Log	Event
19:49:10	365	Main_365	0	X	System Start
19:49:19	365	Main_365	0	X	Tamper On
19:51:11	365	Main_365	0	X	Menu Entrance
19:52:23	365	Main_365	0	X	Menu Entrance
20:00:41	365	Main_365	0	X	Menu Entrance
20:03:44	365	Main_365	0	X	Menu Entrance
20:04:28	365	Main_365	0	X	Menu Entrance
20:36:01	365	Main_365	1	X	Enroll Success
20:36:30	365	Main_365	2	X	Enroll Success
20:36:43	365	Main_365	2	X	Enroll Success
20:37:12	365	Main_365	3	X	Enroll Success
20:38:59	365	Main_365	0	X	Identify Fail
20:39:12	365	Main_365	1	X	Enroll Success

Search Logs

The log search feature provides the ability to search through the consolidated log via date, user ID, user name, device, and/or event.

Screen View

① **Details Button**: Go to the relevant details menu by clicking **Monitor** or **Search**.

② **Log Menu Button**: Go to the Log menu by clicking this button from a different menu.

③ **Option Menus**

- **Date Option**: Select a time frame for an event to be searched for.
- **User ID Window**: Directly enter a user's ID to be searched for.
- **Device Search Window**: Select a device to be searched for.
- **Event Search Window**: Select an event to be searched for.
- **Search Button**: Click this button to search for events with the set options.

④ **Search Results Window**: The search results are displayed.

⑤ **Export Button**: Save the event logs in a CSV file format.

Search Logs

1 Select an option for log search among date, user, device, and event.

- **Selecting a Period:** Click the drop-down calendars to select the timeframe for the search.



- **Selecting a Device**
  i. Click **Select** to display the connected device in a pop-up window.

  ii. Select a device(s) to search.
  iii. Click **Select** to add the devices to the device list.

- **Entering a User ID**: Enter either the ID or name of the user.
  Multiple IDs can be entered by separating each with semicolons (;) as seperators.

- **Selecting an Event**
  i. Click **Select** to display events.
  ii. Select an event(s) to search.



  iii. Click **Select** to add the events to the event list.

2 Click **Search** to display the search results.
The search results may span across several pages.

3 Click **Export**, and then click **Download** in a pop-up window in order to designate a location to save a file in. Event logs will be saved as a file on the designated path.

NOTE

- When exported as a file, the file is saved in the CSV format (',' separator; 'dat' extension). This file can be modified with a text editor or MS Excel.
- The exported file is stored in UTF-8 encoding.
- When using MS Excel, MS Excel must be running prior to opening the exported file via the file open menu.
- If an export file is not downloaded, click the right mouse button and then press '**Save as**'.

Chapter 6

Using the Device Menu

Authentication Mode Configuration

Setting Fingerprint Authentication

Setting Card Authentication

Setting ID Authentication

Setting Other Options

Setting Network

Setting IP Address

Setting WLAN

Setting Serial

Setting Display and Sound Options

Setting Time

Setting Language

Setting Background

Setting Theme

Setting Menu Timeout

Setting Popup Timeout

Setting Backlight Timeout

Setting Show Central Clock Display

Setting Data Format

Setting Volume

Setting Card or Fingerprint Options

Setting a Card Option

Setting a Fingerprint Option

Using the Device Menu

Authentication Mode Configuration

The device operation submenu is used to configure the authentication modes and matching timeout duration. Any modifications will be applied to all the devices connected to the BioStar Lite and having inner web servers. If the device does not have the option, it will default to the closest possible option.



1 Select the desired activation period for each ID authentication mode.
Only one of each active timezone can be set per group.

2 Select if you wish to use dual authenication, private authenication, and/or face detection.

3 Select the maximum time the device should search the database before returning a result.

4 Click **Apply** to apply settings to the all the devices connected to the BioStar Lite.
Click **Default** to reset the menu to its defaults. The changes will not be automatically applied.

Setting Fingerprint Authentication

- **Finger Only**: Authenticates using only a fingerprint.
- **Finger + PIN**: Authenticates using both fingerprint and password.
- **Key + Finger**: Authenticates using both a T/A key and fingerprint.
- **Key + Finger + PIN**: Authenticates using a T/A key , fingerprint, and password.

Setting Card Authentication

- **Card Only**: Authenticates using only a card.
- **Card + PIN**: Authenticates using both card and password.
- **Card + Finger**: Authenticates using both card and fingerprint.
- **Card + Finger/PIN**: Authenticates using card and either fingerprint or password.
- **Card + Finger + PIN**: Authenticates using card, fingerprint, and password.

Setting ID Authentication

- **ID + PIN**: Authenticates with using ID and password.
- **ID + Finger**: Authenticates using both ID and fingerprint.
- **ID + Finger/PIN**: Authenticates using both ID and either fingerprint or password.
- **ID + Finger + PIN**: Authenticates using ID, fingerprint, and password.

Setting Other Options

- **Dual Authentication**: Authenticates using IDs, fingerprints, or cards of two people. The entry relay operates only when two different users try authentication and the second user should try authentication within at least 15 seconds after the first user is authenticated.
- **Face Detection**: Authenticates by detecting a face after successful authentication. This is not facial recognition.
- **Private Authentication**: Authenticates by customized methods for each individual.
- **Match Timeout (sec)**: Sets a length of time (in seconds) for determining successful authentication.

NOTE

- Depending on the type of device, some authentication modes may not be supported ; the device will then, default to the closest possible mode. Refer to **'Authentication Mode Supported by Devices (Page 70)'** for details.

Setting Network

The device network submenu is used to configure the various communication and network settings. Any modifications, excluding TCP/IP, will be applied to all the devices connected to the BioStar Lite and having inner web servers. The TCP/IP settings will only affect the master device.



1 Enter the desired TCP/IP settings values for the master device.

2 Enter the desired WLAN setting values. (Only applies to WIFI devices)

3 Select the desired serial communication settings.

4 Click **Apply** to apply settings to all the devices connected to the BioStar Lite.

Click **Default** to reset any change, which will not be applied to the device.

NOTE

- Modifications to the TCP/IP settings will only affect the master device.
- The settings for serial communication will be applied to all the devices connected to the BioStar Lite and having inner web servers.

Setting IP Address

- **When using a dynamic IP**
  i. Check **Use DHCP** to use DHCP.
  An IP address will be automatically assigned to the device.
- **When using a static IP**
  i. Uncheck **Use DHCP** to use a static IP address.
  ii. Enter the IP address, gateway, and subnet mask.

Setting WLAN

1 Check **Use WLAN** to enable the WLAN feature.

2 Set the following details when checking **Use WLAN**.

3 Enter SSID(up to 32 characters).

4 Set an encryption method (Not Use/WEP/WPA-PSK).

5 If encryption is enabled, enter an encryption key (up to 13 characters).

6 Re-enter the encryption key in the confirmation field to confirm.

NOTE

- If the WLAN is enabled, TCP/IP will be disabled.
- SSID is a unique, 32-byte identifier on each header of packets transmitted over wireless LANs, which is used as an ID for a wireless device when connected.

Setting Serial

- RS232(PC): Available when RS485 is disabled.

  Select a baud rate to enable the port.

  (Not Use/ 9600/ 19200/ 38400/57600/115200).

- RS485(PC): Select a baud rate to enable the port.

  (Not Use/ 9600/ 19200/ 38400/57600/115200).

- RS485(NET): Sets mode for devices connected via RS485.

  (Not Use/ Host/ Slave)

NOTE

- The BioStation T2 can not support both RS232 and RS485 simultaneously.
- A host device can have slave devices connected via RS485.
- When you add a device through **RS485 Search**, the **RS485(NET)** must be set as **Host**.

Setting Display and Sound Options

The device display submenu is used to configure the time and various OSD settings. Any modifications will be applied to all the devices connected to the BioStar Lite and having inner web servers. The OSD settings will only affect devices with a LCD screen.



1 Set the current date and time.

2 Select the desired OSD settings.

3 Click **Apply** to apply settings to all the device connected to the BioStar Lite.
Click **Default** to reset any change, which will not be applied to the device.

Setting Time

You can check or change the time on the Device.

- **Checking Time**

  Click **Get Device Time** to check the time on the master device.

- **Changing Time**

  i. Set the date with a drop-down calendar.

  ii. Set the desired hour, minute, and second.

  iii. Click **Set Device Time** to apply the changed time.

- **Synchronizing with Host PC Time**

  i. Check the **Get PC time** checkbox.

  ii. Click **Set Device Time** to automatically synchronize the device time with the time of the host PC.

Setting Language

You can set the language to be displayed by selecting among **Korean**, **English**, or **Custom**.

Setting Background

You can set the device background to be displayed by selecting among **Logo**, **Notice**, **Slide**, or **PDF**.

Setting Theme

You can set the background theme for the device.

Theme1, **Theme2**, **Theme3**, and **Theme4** are available.

Setting Menu Timeout

You can set the amount of idle time (sec) before the menu disappears.

Always On, **10**, **20**, and **30** are available.

Setting Popup Timeout

You can set the duration (sec) before the popup window disappears.

0.5, **1**, **2**, **3**, **4**, and **5** are available.

Setting Backlight Timeout

You can set the amount of idle time (sec) before the backlight turns off.

Always On, **10**, **20**, **30**, **40**, **50**, and **60** are available.

Setting Show Central Clock Display

You can set to enable or disable the large clock in the center of the LCD.

It can be set to **Use** or **Not Use**.

Setting Data Format

You can set the format for the displayed date.

It can be set as **MM/DD** or **DD/MM**.

Setting Volume

You can set the volume output of the device.

0, **10**, **20**, **30**, **40**, **50**, **60**, **70**, **80**, **90**, and **100** are available.

NOTE

- Applicable OSD settings will vary from device to device.
- The language setting does not change when restoring default values.

Setting Card or Fingerprint Options

The device card/finger submenu is used to configure the various scanner settings. Any modifications will be applied to all the devices connected to the BioStar Lite and having inner web servers.



1 Select a mode for the card scanner.

2 Select various fingerprint scanner settings.

3 Click **Apply** to apply settings to all the devices connected to the BioStar Lite. Click **Default** to reset any change, which will not be applied to the device.

Setting a Card Option

You can set mode for a card to be used as an access control device.

Not Use and **CSN Mode** are available.

> **NOTE**
>
> - The **CSN Mode** uses the CSN (Card Serial Number) to authenticate the user. The CSN of a scanned card will be compared with the CSN information stored within the user DB.

Setting a Fingerprint Option

You can adjust fingerprint authentication settings to be used as an access control device.

- **Security Level**

  You can set the verification level for fingerprint authentication.

  Normal, **Secure**, and **Most Secure** are available. **Normal** is recommended for a regular Time and Attendance. **Secure** or **Most Secure** is recommended for an environment that requires higher access control security.

- **Fast Mode**

  You can set the authentication speed for fingerprint authentication.

  Normal, **Fast**, **Fastest**, and **Auto** are available.

- **Fake Detect**

  You can set the device to enable or disable a preventive test for a fake fingerprint attack. **Use** and **Not Use** are available.

- **Scan Timeout**

  You can set amount of time (sec) to attempt a scan from 1 to 20 .

  If a user does not place a finger on the device within this period, authentication will fail.

- **Sensitivity**

  You can set the sensitivity value from 1 to 7 for the fingerprint scanner of device.

  (1- Most insensitive, 7- Most sensitive)

- **View Image**

  You can set to display or hide a fingerprint image upon a successful scan.

  Use and **Not Use** are available.

  The fingerprint image can be verified on the screen upon scanning and guide the user to correctly place the finger.

NOTE

- Increasing the security level will indirectly increase the FRR(False Reject Rate) because the stricter authentication protocols will reject more inconsistencies.
- Setting **Fast Mode** to **Auto** will set the authentication speed of the device proportional to the total number of templates registered on the device.
- When the sensitivity is set to low, the scanned fingerprint image is displayed in a higher quality. Set the sensitivity to the maximum value in a normal environment. When direct sunlight is present, set the sensitivity to low in order to minimize the effect of direct sunlight.
- Using View Image is helpful in determining if a fingerprint has been properly scanned.
- Applicable fingerprint settings will vary from device to device.

Chapter 7

Using the Access Control Menu

Screen View

Holiday Group Managment

Adding a Holiday

Modifying a Holiday

Deleting a Holiday

Timezone Management

Adding a Time Zone

Modifying a Time Zone

Deleting a Time Zone

Access Group Management

Adding an Access Group

Modifying an Access Group

Deleting an Access Group

Using the Access Control Menu

BioStar Lite supports up to 128 time zones consisting of seven day schedules along with two holiday schedules. Each day in a time zone may include as many as five distinct time periods. In total, BioStar supports up to 128 access groups for which a time zone may be specified for each device.

Screen View

① **Access Control Menu Button**: Go to the User menu by clicking this button from a different menu.

② **Holiday Window**: Check, add, or modify the registered holidays.

③ **Time Zone Window**: Check, add, or modify the registered time zones.

④ **Access Group Window**: Check, add, or modify the registered access groups.

Holiday Group Managment

Holiday groups can be used to setup timezones and access groups.

Adding a Holiday

1 Click **Add**. A holiday adding window is displayed.



2 Enter a name for a holiday.

3 Select **New** in the index field.

4 Select the start date of holidays from the drop-down calendar.

5 Select the duration of holidays from the drop-down calendar.

6 Check **Once** if this is a one-time holiday.

7 Click **Apply/Modify** to add a holiday to the list.

8 Click **Apply** to update the holiday list.
Click **Cancel** to cancel the update.

NOTE

- Up to 32 holiday schedules can be added.

Modifying a Holiday

1 Click on a holiday group from the list. A window for modifying a holiday is displayed.



2 Select a holiday number from the index field.

3 Modify the desired fields.

4 Click **Add/Modify** to update the selected holiday.

5 Click **Apply** to update the holiday list.
Click **Cancel** to cancel the update.

Deleting a Holiday

1 Select a checkbox of a desired holiday group(s).

2 Click **Delete** to remove the selected holiday groups.

Timezone Management

- **Always** and **Never** are default time zones and cannot be deleted or modified.
- You can allow access at all times by selecting **Always**.
- You can restrict access at all time by selecting **Never**.

Adding a Time Zone

1 Click **Add**. A window for adding a time zone is displayed.

2 Enter a name for a time zone.



3 Set a time zone for each day of the week from the General Schedule.

- You can create a schedule by dragging the mouse across the timebar or manual input by clicking on the clock with an arrow pointing right.
- Each day may include as many as five distinct time periods.
- Click the arrow pointing downwards to apply the day's schedule to the following day.
- Drag the mouse across the timebar while pressing the 'Ctrl' button simultaneously, and the newly dragged parts are set as a schedule.

4 Set a time zone for each holiday schedule from the Holiday Schedule menu.
Up to two holiday schedules can be selected.

i. Select a holiday group from the a holiday drop-down menu.
Each day may include as many as five distinct time periods.

ii. Drag on the the mouse across the timebar or manual input by clicking on the clock with an arrow pointing right.

iii. In order to set an additional time zone for a holiday schedule, repeat steps i and ii.

5 Click **Apply** to update the time zone.
Click **Cancel** to cancel the update.

Modifying a Time Zone

1 Select a desired time zone from the list. A window for modifying a time zone is displayed.

2 Re-enter a name to change.

3 Modify a time zone for each day of the week from the schedule.

- You can modify a schedule by dragging the mouse across the timebar or manual input by clicking on the clock with an arrow pointing right.
- Each day may include as many as five distinct time periods.
- Click the arrow pointing downwards to apply the day's schedule to the following day.
- Drag the mouse across the timebar while pressing the 'Ctrl' button simultaneously, and the newly dragged parts are set as a schedule.

4 Modify a time zone for each holiday schedule from the schedule for each holiday. You can change a time zone by selecting up to two holiday schedules.

i. Select a holiday group from the a holiday drop-down menu. Each day may include as many as five distinct time periods.
ii. Drag on the mouse across the timebar or manual input by clicking on the clock with an arrow pointing right.
iii. In order to set an additional time zone for a holiday schedule, repeat steps i and ii.

5 Click **Apply** to pdate the timezone list.
Click **Cancel** to cancel the update.

Deleting a Time Zone

1 Check a checkbox of a desired time zone.

2 Click **Delete** to remove the selected timezones.

Access Group Management

- The access group tool is an advanced feature to provide schedules for each device in a group.
- The devices and timezones must be setup in order to begin access group configurations.
- **Full Access** and **No Access** are default access groups and cannot be deleted or modified.
- You can allow access on all devices at all times by selecting **Full Access**.
- You can restrict access on all devices at all time by selecting **No Access**.

Adding an Access Group

1 Click **Add**. A window for adding an access group is displayed.

2 Enter a name for a new group.



3 Select a time zone to allow access.

4 Select a device to allow access.

5 Click < or > to add and remove access rights from the group.

6 Click **Apply** to update the access control list.
Click **Cancel** to cancel the update.

Modifying an Access Group

1 Click a desired access group. A window for modifying an access group is displayed.

2 Modify the desired fields.



3 Click **Apply** to apply the change.
Click **Cancel** to cancel the change.

Deleting an Access Group

1 Select the checkbox of a desired access group(s).

2 Click **Delete** to delete the selected access groups.

Chapter 8

Using the System Profile Menu

Screen View

System Configuration Management

Backup System Configuration

Restore System Configuration

User Information Management

Backup User Information

Restore User Information

Language Resource Management

Download Language Resource

Upload Language Resource

Using the System Profile Menu

The system profile submenu is used to backup and restore various BioStar Lite server settings.

Screen View



① Go to the System Profile menu by clicking this button from a different menu.

② **System Configuration Management**: Backup or restore the device settings.

③ **User Information Management**: Backup or restore the user information.

④ **Language Resource Management**: Download or change the language resources.

System Configuration Management

The system configuration management submenus are used to backup and restore the system configuration backup file.



Backup System Configuration

1. Click **Backup System Configuration**.
2. When a pop-up window appears, click **Download** within the popup window.
3. Select a location to save the system settings backup files in.
   The device settings backup files will be saved on the designated path.

Restore System Configuration

1. Click **Restore System Configuration**.
2. Click **Browse** within the popup window.
3. Navigate and select the system configuration backup file.
4. Click **Apply** to restore the settings.

   Click **Cancel** to cancel restoration.

NOTE

- The master device may malfunction if the backup files were corrupted.
- If the system configuration backup file is not downloaded, click the right mouse button and then press 'Save as'.

User Information Management

The user information management submenus are used to backup and restore the user DB backup file.

Backup User Information

1 Click **Backup User Information** to create a backup of the User DB.

2 When a pop-up window appears, click **Download**.

3 Select a location to save the user DB backup file.
The user DB backup file will be saved on the designated path.

Restore User Information

1 Click **Restore User Information** to restore a previously backed up user DB.

2 Click **Browse** within the popup window.

3 Navigate and select the user DB backup file.

4 Click **Apply** to restore the user DB.

Click **Cancel** to cancel restoration.

NOTE

- The master device may malfunction if the backup files were corrupted.
- If the user DB backup file is not downloaded, click the right mouse button and then press 'Save as'.

Language Resource Management

The language resource management submenus are used to backup and restore the language table file.



Download Language Resource

1. Click **Download Language Resource** to save a language table from BioStar Lite.
2. Click a language table to restore: **English**, **Korean**, or **Custom**.
3. Select a location to save the language table.

   The language table will be saved on the designated path.

Upload Language Resource

1. Click **Upload Language Resource** to input a language table into BioStar Lite.
2. Select a language system to overwrite: **English**, **Korean**, or **Custom**.
3. Click **Browse** to select the resource file path.
4. Navigate to and select the desired language table.
5. Click **Apply** to apply the change. Click **Cancel** to cancel the change.

NOTE

- In order to change phrases for each language that are displayed on BioStar Lite, the relevant content needs to be modified on the resource files and reapplied to the device.
- When you modify resource files that are downloaded from BioStar Lite, the existing rules for writing resource files must be followed. If not, the device may malfunction.
- If the language resource backup file is not downloaded, click the right mouse button and then press 'Save as'.

Appendix

Understanding the Product Details

Introducing Devices Supporting BioStar Lite

Notes for Authenticating Fingerprints on the Device

Authentication Mode Supported by Devices

Detailed Diagram

Device Connections

Door Connections

Troubleshooting

Glossary

Index

Appendix

Understanding the Product Details

Introducing Devices Supporting BioStar Lite

BioStation T2

BioStation T2 is a device to control access and check attendance based on an IP network with a 5-inch touch screen LCD and face detection technology. It processes up to 1:3,000 authentications within one second with a built-in high-performance CPU and supports various interfaces such as WiFi, PoE, RS485, and Wiegand, while having a video phone and imbedded web server function. Also, it provides an intuitive GUI based on a touch screen and enables authentication by using an RF card and password.

D-Station

D-Station provides three authentication modes that maintain a balance between the security level and process speed through a network-based multifunctional access control with both dual fingerprint and face detection technologies. D-Station adjusts bio-authentication methods according to the accuracy, speed, or high-capacity process requirements of the user in order to enable the user to select the desired optimum performance. Also, it allows you to enter a PIN on the touch screen and supports various RF card authentication methods.

X-Station

X-Station is a device to control access and check attendance with an RF card based on an innovative IP network with a touch screen LCD and face detection technology. It provides an intuitive GUI based on a 3.5-inch touch screen and enables authentication by using an RF card and password. Also, it detects faces with a built-in camera and stores a maximum of 200,000 users by utilizing 1 GB of a built-in flash memory and 256 MB of RAM.

Notes for Authenticating Fingerprints on the Device

Since it is important to scan high-quality fingerprint images when registering fingerprints, please note the details below prior to registering fingerprints.

- Check if the registrant's fingerprints are clean and dry. If needed, place a finger on the sensor again after wiping a fingerprint to be registered with a dry cloth, or blow onto a fingerprint if it is too dry.
- The same fingerprint must be scanned twice in order to register two fingerprints for the same finger. Each user can register two fingers (four fingerprints).
- Do not scan a finger with a scar or faint fingerprint.
- If the fingerprint recognition rate is low, it is recommended to delete the relevant fingerprint information and register a new fingerprint.

In order to obtain high-quality fingerprint information, the registrant should try to cover the entire area of the sensor with a fingerprint. Since it is better to use a finger convenient for placing onto the sensor, it is recommended to register fingerprints of an index or middle finger. The fingerprint can be properly registered by placing a finger onto the sensor and covering the surface of the sensor.

Authentication Mode Supported by Devices

	BioStation T2	BioStation	D-Station	X-Station	BioLiteNet	Bio EntryPlus	XPASS	NOTE
Fingerprint	Fingerprint	1:N Used	1:N Used	X	1:N Used	Finger Card + Finger	X	
	Finger + PW	1:N Used	1:N Used	X	1:N Used	X	X	
	Key + Finger	1:N – OK key/ T&A key	1:N – T&A key	X	1:N – OK key/ T&A key	X	X	
	Key + Finger + PW	1:N -OK key/T&A key	1:N – T&A key	X	1:N – OK key/ T&A key	X	X	
Card	Card	Card	Card	Card	Card	Card + Finger	Card	*For BLN, if fingerprint is set for authentication, card or ID cannot be set for authentication. If you want to set both fingerprint and card for authentication, you should set the Private Authentication. *For BEPL, if only the card is set for authentication, you should set the Private Authentication.
	Card + Finger	Card/ ID + Finger	Card/ ID+Finger	X	Card/ ID + Finger	Card + Finger	Card	
	Card + PW	Card/ ID+PW	Card/ ID+PW	Card/ ID+PW	Card/ ID+PW	Card + Finger	Card	
	Card+ PW/ Finger	Card/ ID+PW/ Finger	Card/ ID+PW/ Finger	Card/ ID+PW	Card/ ID+PW/ Finger	Card + Finger	Card	
	Card + Finter + PW	Card/ ID + Finger + PW	Card/ ID + Finger + PW	Card/ ID+PW	Card/ ID + Finger + PW	Card + Finger	Card	
ID	ID+Finger	Card/ ID + Finger	Card/ ID + Finger	X	Card/ ID + Finger	X	X	
	ID + PW	Card/ ID + PW	Card/ ID + PW	Card/ ID+PW	Card/ ID + PW	X	X	
	ID + PW/ Finger	Card/ ID + PW/ Finger	Card/ ID + PW/ Finger	Card/ ID+PW	Card/ ID + PW/ Finger	X	X	
	ID + Finger + PW	Card/ ID + Finger + PW	Card/ ID + Finger + PW	Card/ ID+PW	Card/ ID + Finger + PW	X	X	

Detailed Diagram

Device Connections



Door Connections

- **Standalone**

  An inner device controls the door lock and is connected with an outer device by the general input trigger. (Available only when RTE is set to N/O)



- **Secure**

  An inner device controls the door lock and is connected with an outer device by the RS-485 ports (using encrypted communication with tightened security).



Troubleshooting

When any issues arise while using BioStar Lite, you can request technical support from Suprema via email (sales@supremainc.com). When you send an email, please include the following information:

- The version of BioStar Lite that you are using
- The name of the Suprema device that you are using
- A detailed error message if an error message appears
- A brief description regarding the issue
- Your name and title

Glossary

- **Resource Files**

  Resource files refer to files in which phrases displayed on BioStar Lite are saved.

- **CSN Card Mode**

  In CSN card mode, when the card is inserted, the identification number on the card is authenticated by being compared to the identification number registered on the device. When a user is registered, the identification number assigned to the card is saved on the device.

- **APB (Anti-passback)**

  Anti-passback is a function that restricts access to each device. APB blocks the unauthorized access attempts by those who, with no previous access authentication records, try to enter using an accessible card or follow the authorized user into the office or building.

- **Distributed Processing**

  In the BioStar Lite system, the authentication database is distributed to each device. Hence, authentication is faster and can continue even when other parts of the system are offline.

- **Door**

  Doors are physical barriers that provide entry into a building or space. At least one device must be connected to a door to provide access control. However, two devices should be connected to support the anti-passback feature.

- **SSID (Service Set Indentifier)**

  SSID is a unique, 32-byte identifier on each header of packets transmitted over wireless LANs, which is used as an ID for a wireless device when connected. Since SSID distinguishes one wireless LAN from another, all APs or wireless devices to be connected to a particular wireless LAN must use the same SSID.

- **Fingerprint Authentication**

  Fingerprint Authentication is an automated process of matching two human fingerprints: the previously recorded one and the currently entered one. This product incorporates Suprema's exclusive, award-winning algorithms for recognizing fingerprints.

- **Fingerprint Sensor**

  A fingerprint sensor is an electronic device used to capture digital images of fingerprint patterns. The fingerprint captured by the fingerprint sensor is saved as raw data. These raw data are processed to create a biometric template (a collection of characteristics of an individual fingerprint) that is stored and used for user authentication.

- **Biometrics**

  Biometrics refers to a technology that utilizes a part of the human body to identify an individual. BioStar Lite incorporates Suprema's exclusive fingerprint recognition technologies, allowing access only to those who are identified biometrically.

- **FRR (FRR, False Reject Rate)**

  The false rejection rate is a probability that the system will incorrectly reject an access attempt by an authorized user. The FRR is the ratio of the number of false rejections to the number of all identification attempts.

- **Secure I/O**

  Secure I/O is an extended I/O box that performs encoded RS485 communications with devices. If the built-in I/O of a device is used, the door may be opened when the device is physically damaged. If the Secure I/O is used, the door can be prevented from being opened when the device is physically damaged.

Index

A

Adding a Holiday 55
Adding an Access Group 60
Adding a Time Zone 57
Adding Devices 14
Adding Doors 17
Administrator Account Management 22
Anti-passback 18
Authentication Mode 70

B

Backup System Configuration 64
Backup User Information 65
BioStar Lite Firmware version 21

C

Card Authentication 43
Card ID 32
Closing Doors 20
CSN Mode 51
CSV Format 40

D

Delete a Holiday 56
Deleting an Access Group 61
Deleting a Time Zone 59
Device Connections 71
Door Connections 72
Door Management 17
Download Language Resource 66
Dual Authentication 43

E

Entering General Information 31
Event Logs 36

F

Face Detection 43
Fake Detect 51
Fast Mode 51
Fingerprint Authentication 43

I

ID Authentication 43

M

Match Timeout 43
Modifying a Holiday 56
Modifying an Access Group 61
Modifying a Time Zone 58
Modifying Door information 19

N

New User Registration 30

O

Opening Doors 20

P

Private Authentication 43

Q

Quick Menus 26

R

Registering a Card 32

Restore System Configuration 64

Restore User Information 65

RS232 46

RS485 46

RS485 Search 14

S

Scanning a Fingerprint 32

Scan Timeout 51

Searching Users 29

Search Logs 37, 38

Security Level 51

Sensitivity 52

Setting a Language 21

Setting Background 48

Setting Backlight Timeout 49

Setting Data Format 49

Setting IP Address 45

Setting Language 48

Setting Menu Timeout 49

Setting Network 44

Setting Popup Timeout 49

Setting Serial 46

Setting Show Central Clock Display 49

Setting Theme 48

Setting the Volume 49

Setting Time 48

Setting WLAN 45

T

TCP Search 14

U

UDP Search 14

Upload Language Resource 66

User Information Modification 33

V

View Image 52

Viewing Help Manual 21

Suprema Inc.

16F Parkview Tower, 6 Jeongja, Bundang, Seongnam, Gyeonggi, 463-863 Korea

Tel: +82-31-783-4502 I Fax: +82-31-783-4503

Email: sales@supremainc.com I Homepage: www.supremainc.com